ReadiVac™

12 VOLT AUTO VAC
INSTRUCTION MANUAL



MODEL# 36104

REASON PLEASE CALL

If you should experience a problem with your ReadiVac purchase, call 1-800-982-5233. In most cases, a ReadiVac representative can resolve your problem over the phone. If you have a suggestion or comment, give us a call. Your feedback is vital to the success of ReadiVac's quality improvement program.

SAVE THIS MANUAL FOR FUTURE REFERENCE

FULL ONE (1) YEAR WARRANTY

Your ReadiVac product is warranted for one year from date of purchase, by original purchaser, against defects in material and workmanship. Within one year of purchase, should your product fail, return it to your place of purchase for replacement. If you do not receive satisfaction from the dealer, you may return the unit directly to ReadiVac, 118 East Douglas, Walnut Ridge, Arkansas 72476, for repair or at the sole option of ReadiVac, replacement. This warranty does not apply to belts, brushes, disposable dust bags or service calls. All merchandise returned to ReadiVac must include a dated sales receipt and must be returned prepaid to ReadiVac in a reshippable carton.

THERE IS NO OTHER EXPRESS WARRANTY

Implied warranties, including those of merchantability and fitness for a particular purpose, are limited to one year from the date of purchase. Some states may not allow the limitation or exclusions of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is the exclusive remedy, and liability for incidental and consequential damages under any and all warranties is excluded. This product is not intended for commercial use.

IMPORTANT SAFETY INFORMATION

Basic safety precautions should always be followed when using electrical appliances
PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE UNIT.

⚠ **WARNING:** This product contains chemicals, including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

⚠ **WARNING:** To reduce the risk of electrical shock, fire or injury:

- Close supervision is necessary when used by or near children. Do not allow to be used as a toy.
- To protect against risk of electrical shock, do not put unit in water or other liquid.
- Do not use to pick up flammable, toxic or combustible liquids such as gasoline or use in areas where they may be present.
- Do not vacuum any electrical appliance while they are plugged in.
- Do not operate in the presence of flammable fumes, liquids or explosives.
- Do not operate with a damaged cord. If the appliance malfunctions, is left outdoors, dropped in water or is damaged in any manner return to an authorized service center for examination and repair.

- Do not use ReadiVac dry hand vacs outdoors or on wet surfaces. Do not use the wet/dry hand vacs outdoors.
- Do not disconnect plug by pulling on cord. To disconnect grasp the plug, not the cord. Keep cord away from heated surfaces. Do not pull cord around sharp edges or corners.
- Do not allow the cord to touch hot surfaces.
- Store vacuum after each use to prevent tripping accidents.
- Plug the charger directly into a cigarette lighter.
- Do not operate the 12V Auto Vac while driving the vehicle.
- Keep hair, loose clothing, fingers and the like away from openings and moving parts.
- Do not attach accessories when unit is running.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not operate with any openings blocked; keep free of dust, lint, hair and the like.
- Do not pick up any sharp objects that may damage vacuum or filter.
- Do not operate the unit without filter and dust cup in place. Replace a damaged filter promptly.
- Do not pick up cigarettes, hot ashes, matches or similar materials.
- Do not use on or near hot surfaces.
- Intended for household use only and not for commercial or industrial use.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Unplug the charger from outlet before performing any cleaning or maintenance.

SAVE THESE INSTRUCTIONS

OPERATION

For 12 Volt units, remove the cigarette lighter from receptacle. Plug the power cord adaptor into receptacle.

1. Push the power switch forward to operate.



2. To use with accessories firmly push accessory into open end of dust cup.





3. Do not fill the dust cup beyond the end of the intake chute. If there is any liquid in the dust cup, do not turn the unit upside down, sideways, point the nozzle upward, or shake the vac excessively.

4. After picking up liquid substances clean the vac and filter immediately. Mold and mildew may form if the unit is not properly cleaned after wet pickups.

CLEANING THE PRODUCT

WARNING: Never use the Hand Vac without its filters.

NOTE: The filters are re-usable, do not confuse them with disposable dust bags, and do not throw them away when the product is emptied. We recommend that you replace the filters every 6-9 months. Please call 1-800-982-5233 to order your replacement filter.



- To empty dust cup, press the release button and remove the dust cup by pulling it downward away from unit. To replace the dust cup, place it back onto the handle and click firmly into place.



- While holding the dust cup over a wastebasket, pull out the hard filter and diverter.
- Empty the dust from the dust cup and wash if necessary.
- Wash the filter regularly using warm, soapy water and ensure that it is completely dry before using it again. The cleaner the filters are, the better the product will perform. It is very important that the filter is correctly in position before use. The dust cup can also be washed in warm soapy water. Ensure that it is dry before re-attaching.

IMPORTANT: Maximum dust collection will only be obtained with clean filters and an empty dust cup. If dust begins to fall back out of the product after it is switched off, this indicates that the dust cup is full and requires emptying.

- Never immerse the product in water. A damp cloth and soapy water should be used to clean the exterior of the motor section. Always ensure the product is completely dry before re-use or storing.

NEVER OPERATE WITH FILTER OR DUST CUP REMOVED!

ADDITIONAL INFORMATION

ACCESSORIES:

Accessories are stored on the product and are fitted into the nose of the product for use.

ReadiVac™

P.O. BOX 29
118 EAST DOUGLAS
WALNUT RIDGE, ARKANSAS, U.S.A 72476
(800)-982-5233